

2015 4 Point Locking Instructions.

Contents i

2 x lock Keeps (a plate with two holes)
2 x lock latches (chrome latch with 4 holes in each corner)
3 x M6 Bolts 10mm
3 x M6 Washers
1 x Swivel plate (a plate with 2 white rollers)
1 x Length of cable
10 x Phillips Tech Screws (self Drill)
4 X Hex Head Tech Screws .

Tools required .

Cordless drill with Phillips head attachment
8mm socket attachment
10mm ring spanner
Tape measure .
Oil.

Warning !

Always have an assistant on the inside of your door when adjusting the locking , you could easily lock your self out .

This job should take no more than 20 mins , for an average DIYer, If you need this item fitted please call your supplier who will direct you to an approved installer .

Instructions

1 Line up the chrome latches with the bottom of the door panel and the rubber seal, screw in place using 4 Phillips head Tech screws (self drilling) do not cover the rubber seal simply push the latch against it .

Repeat for the opposite side .

2 , measure where the centre of the door is and fit the plate with the return edge at the bottom of the door , use 2 x Phillips head tech screws .

3 Fit the Keep using 2 x Hex Head screws using an 8mm socket attachment to your drill .they locate under the latch and should overlap the latch keep at least 10mm .

Repeat for other side .

4 Start at one side and using 1 x M6bolt and washer , loop the cable around the bolt and tighten down , thread the cable around one of the wheels on the swivel plate and up to the lock , fix with 1x M6 bolt and washer , thread the cable to the other latch around the swivel plate and tighten,

Check the operation from the inside opening and closing the door and adjusting the latches in or out for a perfect operation , oil all latches .

