

Instructions for Programming Old Style Handsets

OLD STYLE HANDSETS AND CONTROL BOXES (handset ~75mm x 42mm, light grey in colour with one button).

To match handsets to control boxes you must gain access to the security code banks (rows of movable plastic prongs).

The code banks in the handset can be found by removing the cover.

The code banks in the control box can be found by removing the cover of the control box, and are located on the printed circuit board (PCB).

To obtain handset / control box compatibility match the codes.




Pre 1993 code banks contain two banks of 8 two-way switches.

Post 1993 code banks contain one bank of 9 three-way switches.

To mix the two, e.g. old type handset and new type PCB or vice versa, the code sheet will be required.


This sheet contains forty matching security codes; the left hand code is for post 1993 code banks, the right hand code is for pre 1993 code banks.

EXAMPLES FOR CODE MATCHING TRINARY SWITCHES WITH BINARY SWITCHES







OUTSIDE (FRONT)




OUTSIDE (BACK)



INSIDE



MAGNIFIED VIEW OF DIP SWITCHES IN OLD STYLE HANDSET



OLD STYLE CIRCUIT BOARD (9 WAY SWITCH)
COMPATIBLE TRANSMITTER: GTX3, GTX M27